

Ingenico Lane 3000 Pin Pad

-Adjusting Date/Time Settings

1. With the Pin-Pad displaying "Welcome" on the LED screen,
 - type " **2-6-3-4** "
2. Press " **F** " for menu on the Pin-Pad to enter configuration settings
3. Using the Up & Down keys,
 - select " **Tetra Admin** " followed by the **>Green circle button**
4. Scroll down to **>3: Set Date & Time** followed by the **>Green Circle**
 - Select **>1: Set Date** followed by the **>Green Circle** or,
 - Select **>2: Set Time** followed by the **>Green Circle**
5. For either option above, select the **Yellow back** button to clear the contents
6. Enter the **current date or time** followed by the **>Green Circle** button
7. When finished, select the **>Red button** until "**Welcome**" is again displayed on the LED screen.