

Adjusting Ingenico Lane3000 Pin Pad Date & Time Settings

1. On the main screen of the pin pad, enter “**2-6-3-4**” followed by the “**F**” button.
2. Arrow down to “**Tetra Admin**” followed by pressing the “**Green**” button.
3. Scroll down to “**Date & Time**” and press the “**Green**” button.
4. Scroll down to “**Set Time/Date**” and make adjustments.
5. When complete, select the “**Red**” button until back to the “**Welcome**” display.